

Instruction Manual

LeChef Electric Water Urn

Thank you for choosing our LeChef Hot Water Urn Series. Before use, please read the following instructions carefully.

Warnings & Precautions

1. For first time use fill unit with water up to a maximum level indicated, squeeze a fresh lemon (or lemon juice) into water. Boil water and lemon juice, pour out water and wash out urn in cold water.

Now the water urn is ready for use.

2. **DO NOT** immerse unit in water.
3. Lid must be locked before use.
4. **DO NOT** fill unit with water while urn is plugged into the power socket.
5. If tap water is used calcium deposits will accumulate on the sides of the unit and or the heating element. This will cause an increase in energy consumption. To keep unit in its best condition and prolong the life of the unit, we recommend de-scaling any calcium deposits found.
6. Before plugging in the unit, the unit must be filled with water up to the maximum water level indicated. **DO NOT** fill unit with water passed this level. When water is up to the minimum level, water must be added.
7. **DO NOT** operate unit without sufficient amount of water at any time.
8. Unit can only be used indoors and on a flat surface.
9. **DO NOT** move unit after filled with water.
10. Indicator lights- installed with two indicator lights, one at each end of the switches. Left bulb lighted when turn on "boiling" option, right bulb lighted when turn on "keep warm" option.
11. **DO NOT** leave unit unattended.
12. **Keep away from children.**
13. Any service or repair on unit should be performed by an authorized service center.

Warranty will be voided if serviced by an unauthorized service center or if misused.

Operation Instruction

1. **Boiling Mode** – Use switch marked "Boiling"

To boil the water press switch marked "boil", light will go on thus activating the heating element. Once the water has finished boiling, manually turn off "boil" switch to stop boiling and to prevent dry boiling. If "boil" switch is not in off mode, unit will continue to boil

2. **Keep Warm Mode** - Use switch marked "Keep Warm"

Before Shabbat water must come to a full boil (as stated in section 1 above)

After following the steps in Section 1, Keep Warm switch will need to be turned on manually by pressing the "keep warm" switch (indicator light go on).

Thermal Protection - Safety Switch

This unit is equipped with a safety feature, which stops the unit in case of over-heat or lack of sufficient quantity of water. The reset button is located on the bottom left side of the unit. If the unit shuts off and the power light is off, you must disconnect the unit from power supply for 60 minutes, unscrew reset buttons cap and press reset button.

Now fill the urn with water and activate it; if unit does not turn on properly pass; unit will need to be sent in to an authorized service center.

Maintenance

Cleaning the Unit

It is important that the unit and its accessories be kept clean after each use.

For dirt or smudges on the outside of the unit, it is recommended to clean with a soft damp cloth, and if necessary, with a non-corrosive and/or non-abrasive detergent or cleanser.

De-scaling:

If tap water is used calcium deposits will accumulate on the sides of the unit and or the heating element. This will cause an increase in energy consumption. To keep unit in its best condition and prolong the life of the unit, we recommend de-scaling any calcium deposits found.

1. Pour 7 oz. (200-ml) fresh lemon juice or condensed lemon juice on the Heating Element at the bottom of the Urn.
2. Wait 5-6 minutes to allow the lemon juice to run through the sediments.
3. You may use a brush with soft bristles to brush the Heating Element lightly and gently.
4. Repeat steps 1-3, until calcium deposits are removed.
5. Use a dry cloth to wipe the lemon juice away.
6. Pour clean water into the Urn, brush the Heating Element lightly and gently until there is no more lemon taste and smell.
7. The unit can be used again.

LeChef

For service in US contact:

Royalux Inc.

105 Pleasant Avenue

Upper Saddle River, NJ 07458

201-785-8840

Service@royaluxusa.com