

POPCORN PRICING SHEET - CONFETTI PARTY SUPPLIES, TENTS AND RENTALS

Surrey 604-531-4242

Popcorn Machine 1 Day Rental	\$50.00
With cart	\$65.00
All-in-one Popcorn	\$ 2.29
Makes 6 small (4oz.) Bags	
100 small bags	\$ 9.75

If you made 100 small bags of popcorn

Popcorn Machine 1 Day Rental	\$50.00
With cart	\$65.00
17 All-in-one Popcorn	\$38.93
100 small (4oz.) bags	\$ 9.75
Total	\$98.68
(With cart)	\$113.68

If you made 200 small bags of popcorn

Popcorn Machine 1 Day Rental	\$50.00
With cart	\$65.00
34 All-in-one Popcorn	\$77.86
200 small (4oz.) bags	\$19.50
Total	\$147.36
(With cart)	\$162.36

If you made 300 small bags of popcorn

Popcorn Machine 1 Day Rental	\$50.00
With cart	\$65.00
50 All-in-one Popcorn	\$114.50
300 small (4oz.) bags	\$29.25
Total	\$193.75
(With cart)	\$208.75

If you made 400 small bags of popcorn

Popcorn Machine 1 Day Rental	\$50.00
With cart	\$65.00
67 All-in-one Popcorn	\$153.43
400 small (4oz.) bags	\$39.00
Total	\$247.43
(With cart)	\$262.43

Abbotsford 604-744-2223

Popcorn Machine 1 Day Rental	\$50.00
With cart	\$65.00
All-in-one Popcorn	\$ 2.29
Makes 4 large (6oz.) Bags	
100 large bags	\$ 13.75

If you made 100 LARGE bags of popcorn

Popcorn Machine 1 Day Rental	\$50.00
With cart	\$65.00
25 All-in-one Popcorn	\$57.25
100 large (6oz.) bags	\$13.75
Total	\$121.00
(With cart)	\$136.00

If you made 200 LARGE bags of popcorn

Popcorn Machine 1 Day Rental	\$50.00
With cart	\$65.00
50 All-in-one Popcorn	\$114.50
200 large (6oz.) bags	\$27.50
Total	\$192.00
(With cart)	\$207.00

If you made 300 LARGE bags of popcorn

Popcorn Machine 1 Day Rental	\$50.00
With cart	\$65.00
75 All-in-one Popcorn	\$171.75
300 large (6oz.) bags	\$41.25
Total	\$263.00
(With cart)	\$278.00

If you made 400 LARGE bags of popcorn

Popcorn Machine 1 Day Rental	\$50.00
With cart	\$65.00
100 All-in-one Popcorn	\$229.00
400 large (6oz.) bags	\$55.00
Total	\$334.00
(With cart)	\$349.00

**Prices do not include taxes or delivery.

Popcorn Machine Instructions

1. Plug in machine.
2. Turn on (I) kettle heat switch. (Left-most of the 3 orange lit switches)
3. Turn on (I) agitator switch.
4. Add 6 oz. of popcorn to kettle pot. Add salt to taste.
5. Immediately add ¼ cup oil and close cover.
6. When popping slows to 3-5 seconds between pops, lift cover, dump kettle and repeat steps 4 & 5.
7. On last batch, turn off (O) kettle heat switch when corn starts to pop.

Warning: Do not leave kettle heat on when not popping. Always add corn first then oil to kettle.