



## **Rental of the Slush Machine**

### **Customer Information**

- Do not pick up the machine by the drink compartments
- Double check that the drink compartments are locked into place before filling with drink mix
- Keep sides uncovered to allow for proper air ventilation
- Keep slush levels above the swirling cylinder
- Keep slush levels below the max line indicated on the drink compartment
- Allow 30-45 minutes for the slush to freeze  
Note: Machine could take up to 1 hour if outdoor temperatures are warmer
- **Do NOT add alcohol to the machine.**
  - **Slush mixture will not freeze if alcohol is added**

### **In the Event of a Power Outage:**

- When power returns, change both switches from #2 to #1
- Run the machine on #1 for about 10-15 minutes then return to #2

### **After Your Event:**

- Add water to any remaining slush and drain the remainder from the drink compartments
- Rinse out the machine by running water through the drink compartments until the water runs clear
- Ensure that the machine is completely powered off
- Do not disassemble any machine parts.